




Patient Name:
Date of Assessment:



# Sleep Suit or Sleep Shorts Order Form



Measurements for Sleep Suit or Sleep Shorts - Circumference		Left (cm)	Right (cm)
A	Level with umbilicus 1cm less than "at rest" circumference.		
B	Level with chest in line with the axillary crease or top of high shorts.		
E	Base of the neck.		
J	Level with Anterior Superior Iliac Spine (ASIS).		
2	Shoulder joint from base of the neck (at point where neck meets shoulder below ear lobe), under the axilla and back to the same point. (Scapula set against the chest wall and the arm by the side of the body). One should be able to slide 1 finger under the tape measure at the front of the axilla.		
3	Shoulder joint acromion process under the axilla and back to the same point. (Scapula set against the chest wall and the arm by the side of the body). One should be able to slide 1 finger under the tape measure at the front of the axilla.		
13	Leg level with the groin and gluteal fold.		
13A	Mid-thigh level with muscle bulk 5mm less than "at rest" circumference.		
14	Above knee at suprapatellar margin or where shorts end.		
Measurement for Sleep Suit or Sleep Shorts - Lengths		Left (cm)	Right (cm)
C	Point level with axillary crease measure down side to a point level with umbilicus or top of shorts to point level with umbilicus.		
D	Point level with umbilicus to Anterior Superior Iliac Spine (ASIS).		
F	2cm below sternal notch to umbilicus on the anterior surface of the chest with the ribs held in best position of alignment. This measurement dictates the scoop of the neck or same as 'C' for high shorts.		
20	Inside leg groin to knee or end of SDO.		
22	Point level with umbilicus on anterior surface to knee or end of shorts.		

**NOTE: Sleep Shorts**  
**E, 1, 2 and 3 are not required for Sleep Shorts garment.**

Essential measurements for Sleep Suit - Lengths		Left (cm)	Right (cm)
1	Base of neck to acromion process.		